

## 1930-S **IGIENIKAL**

**Fresh** 



**DESCRIPTION** Fragranced phosphoric acid and citric acid-based cleaner and descaler, formulated for removing dirt, limescale and soap scum from all surfaces

Rapidly dissolves dirt, limescale and soap scum from sinks, shower cubicles, taps, bathroom suites, tiles, etc. **SPECIFICATIONS** 

Contains quaternary ammonium salts Leaves a pleasant fragrance Does not damage chrome finish

Product is ready to use. Apply product directly onto the surface to be cleaned. Leave to work for a few minutes and then rub with a clean, damp cloth. Rinse thoroughly with water. **HOW TO USE AND DOSING** 

**SPECIFICATION** Appearance: transparent green liquid pH: 2.2 +/- 0.5 Specific weight [g/ml]: 1.040 +/- 0.020

The data given above are typical manufacturing values and not a specification.

PRODUCT COMPATIBILITY Do not mix with products containing chlorine. Do not use on acid-sensitive surfaces like marble, agglomerate marble, travertine and other limestone surfaces. Check acid resistance

of surfaces before use. Immediately remove splashes of solution from acid-s

The product is formulated for professional use only. Store in original containers. Avoid extreme temperatures. Consult safety sheet for further information on use and disposal. **USE & STORAGE PRECAUTIONS** 

**CERTIFICATIONS/** The surfactants contained in this product are biodegradable according to the criteria defined by Regulation (EC) 648/2004 and subsequent amendments. **CONFORMITY** 

**CHEMICAL COMPOSITION** Consult safety sheet for further information on product ingredients.













Discover further informations on your smartphone.







