

1804-S **SANI ACTIVE**



DESCRIPTION

Ready-to-use universal disinfectant degreaser

SPECIFICATIONS

SANI ACTIVE – Ready-to-use bactericidal universal degreaser Its formula is designed to disinfect and thoroughly degrease all surfaces, removing even stubborn grime. SANI ACTIVE – degreases and removes germs and bacteria from all surfaces in kitchens, bathrooms, offices, public environments, vehicles and waste receptacles. Recommended also for the agrifood and health industry, on food contact surfaces, and surfaces in contact with the elderly, babies and children. Suitable in all cases where cleaning and disinfection must take place in a single operation.



HOW TO USE AND DOSING

HOW TO USE For normal cleaning spray directly on the surface to be cleaned and dry with a cloth or paper. For disinfection spray on and leave to work for at least 15 minutes, then dry with a cloth, paper or rinse.



Appearance: Transparent colourless liquid

pH: 11.0 +/- 0.5

Specific weight [g/ml]: 1.010 +/- 0.020 100 g of product contains: Pure N-(3-aminopropyl)-N-dodecylpropane-1,3 diamine 0.32g,

coformulants and water q.s. to 100g.

The data given above are typical manufacturing values and not a specification.

ADDITIONAL INFORMATION

Microbiological activity test: EN1276 "Bactericidal activity with interfering substances", EN1650 "Yeasticidal activity with interfering substances", EN13697 "bactericidal and/or yeasticidal activity surface test"

PRODUCT COMPATIBILITY

Following recommended use methods it can be used on all materials commonly found in kitchens/used to manufacture various utensils. If in doubt, test material compatibility on a small concealed part before use.

USE & STORAGE PRECAUTIONS

The product is formulated for professional use only. Store in original containers. Avoid extreme temperatures. Consult safety sheet for further information on use and disposal.

CERTIFICATIONS/ CONFORMITY

The surfactants contained in this product are biodegradable according to the criteria defined by Regulation (EC) 648/2004 and subsequent amendments. Product registered as Medical Surgical Device - Registration no. 20440.

CHEMICAL COMPOSITION

Consult safety sheet for further information on product ingredients.











Discover further informations on your smartphone.







